


Kamerę aktualizujemy przy pomocy programu:

ftp://ftp.eltrox.pl/OPROGRAMOWANIE/KAMERY%20IP/EC-101_102HDS/app_pnp_upgrade.NEW.exe

Uruchamiamy program, klikamy *Search LAN IP camera*, wybieramy znalezionej kamerę



The screenshot shows a web interface for camera management. At the top, there are two buttons: 'Search LAN IP camera' (highlighted with a red box) and 'Upgrade Firmware'. To the right of these buttons is a 'Language:' dropdown menu currently set to 'English'. Below this is a login section with four input fields: 'IP address' containing '192.168.1.107', 'Port:' containing '81', 'Account:' containing 'admin', and 'Password:' containing '*****'.

Wpisujemy ewentualne hasło, domyślnie jest wpisane fabryczne 888888.

Klikamy *Upgrade Firmware*. Czekamy na zakończenie procesu aktualizacji i restartu kamery

Wyróżniamy dwa etapy aktualizacji, aktualizacja ROM oraz aktualizacja serwera WEB.

Czekamy na zakończenie, ewentualnie potwierdzamy wyświetlone komunikaty.

Powinien pojawić się w logu napis **IP Cam is Working!**